

# DISABLED REFUGE SYSTEM

## OPERATING INSTRUCTIONS

### IN CASE OF EMERGENCY



- All Red flashing lights indicate the refuge remote is active and a call can be made.
- Press the 'Press for Help' button to initiate a call.
- All Red lights will illuminate and a ring tone will sound.
- The call will be answered. While the conversation is in progress the Red lights will Flash.
- Wait for the operator to finish speaking before replying.
- Speak clearly in the direction of the unit. Do not press or hold the 'Press for Help' button during a call.
- When the conversation finishes the Red lights will remain on. The operator is kept aware that you have made a call from this location and can contact you again.
- If you want to speak to the operator again press the 'Press For Help' button.