

EMERGENCY CALL POINT

OPERATING INSTRUCTIONS


IN CASE OF EMERGENCY









Press the 'CALL' button to initiate a call.







The operator is kept aware that you have made a call from this location and can contact you again.

 If you want to speak to the operator again press the 'CALL' button.



